



How to install the outer window curtain?



The outer window curtains are provided as additional accessories. You do not have to use it to block sunlight if you have inner curtains. But outer curtains also help protect the wood from UV rays. If you are leaving the yurt unoccupied for an extended period, it is

recommended to attach the outer cover, especially if your yurt has an oil-based exterior paint with motif decorations.

1. There are three sections of the outer curtain for each window. Each section is hand-marked either as “top”, or “middle”, or “bottom” in the back.
2. Start with the section marked as the “top”. Hold the top section right below the window cap and mark the spots corresponding to the eyelets.



3. Drill about a ½ inch hole using the drill bit provided at the marked spots.



4. Screw the hexagonal screws using the special bit provided.



5. Attach the “Top” section using the butterfly-shaped nuts, provided.
6. Then mark the spots corresponding to the eyelets at the bottom of the “Top” section, and drill the holes and screws. These screw will also be used to hold the top of the “Middle” section.
7. Repeat the process for the bottom section.